

Ezy Walk Harness

A Front Attached Harness will help you with loose lead walking. It helps you have more control and guide the dog; it reduces the chance of damage to the back and spine. The following pictures will help you remember the steps to use

Hints For Fitting The Harness

Try to stand beside the dog to fit the harness.


Take harness off dog to adjust straps.

Reward constantly during the fitting process.

Examine the harness regularly for wear and tear.

Check regularly to ensure the harness fit is correct as the dog grows.

The darker but complimentary colour is the belly strap



The backstrap is the lighter colour strap that does not have the rings on it.

The lighter coloured strap with the lead ring on it is the chest strap

The straps should be tight enough so that only one finger fits comfortably between the strap and the dog.



1




Undo the buckle on the chest strap. Hold the harness with the lead ring pointing down.

2



Slip harness over the dog's head.

3



Do up the buckle on the belly strap.

4



The angles between all the straps should form a right angle

